



Chiminea

The Big Green Egg Chiminea offers the warmth and ambiance of an outdoor fireplace with our advanced ceramic technology, making it a great addition to your deck or patio. It burns wood



or charcoal, withstands rain even when hot, and has a screened front to prevent the escape of stray sparks. The Big Green Egg Chiminea can be used as a portable barbecue grill by adding the optional cooking grid, a great choice for heating and cooking.

CHIMINEA (CHIM)

Optional Stand (CHIMS) shown at right

Optional Nest (NEST-L)

Optional Cooking Grid (9P)

Height 31" - Chiminea only

36" - with stand

43.5" - with nest

Diameter 19" - at base

Weight 55 lbs. - Chiminea only



**Warm up your outdoor living space
with our CHIMINEA!**

ASSEMBLY

- The Chiminea is packaged in five parts:
 1. Base
 2. Spark Arrester (round mesh screen)
 3. Cone
 4. Cap
 5. Door/Screen
- Unpack the Chiminea and place the base inside the stand (optional). If you have not purchased the stand, set the base on a concrete patio stone. **Never place the Chiminea directly on a wooden surface.**
- Place the Spark Arrester on top of the base, then place the Cone on top of the Spark Arrester and Base. The Door/Screen should be inserted into the front opening of the Base.
- The cap is provided for protection from the weather while not in use.

STARTING THE FIRE

- You can burn wood, natural lump charcoal or fireplace logs in your Chiminea. Add a Big Green Egg Fire Starter block and light with a lighter or long match. No lighter fluid is needed. Add more fuel as needed.

SAFETY TIPS

- **Do not touch when in operation.**
- **Do not operate near combustible materials.**
- **Do not allow unsupervised children or pets near Chiminea.**
- **The Chiminea is designed for outdoor use only, and it should be operated in a well-ventilated area. Do not use this product indoors or in a closed area. The Chiminea may be stored outdoors.**
- **The Big Green Egg Chiminea has a one year warranty.**

